



The **INSTANT MATCH® WIRELESS** transformer must be registered with the **Mira Advance Extra WIRELESS Shower** to establish a reliable connection.



- Move the jumper on the Whale **INSTANT MATCH®** transformer to the **Mira Advance Extra WIRELESS** setting.
- Move the jumper in the **Mira Advance Extra WIRELESS Shower** (rear of front cover) to the **WIRELESS** setting.
- Ensure the transformer is mounted vertically.
- Do not mount the transformer behind foil backed board or insulation.



1. Turn mains electric power supply to the shower **OFF**.



2. Set the shower temperature to **FULL COLD**.



3. Switch mains electric power to the **INSTANT MATCH®** transformer **ON** Indicated by a flashing **GREEN** then **RED** light on the transformer **TEST BUTTON**.

YouTube



Scan QR code for
Registration video

Contact us



4. Turn mains electric power supply to the shower **ON**. This illuminates the **BLUE** light on the shower **START - STOP** button.



5. **IMPORTANT** Within 30 seconds press and hold the transformer **TEST BUTTON**

After a delay of up to 15 seconds the shower will give a long audible bleep and the transformer **LED** will begin to flash **GREEN** on button release.

This indicates successful registration.

6. Turn shower off and begin commissioning the shower as normal. If you have any difficulties refer to the trouble shooting guide.

